

CHANGING TIRES

HOW TO SAFELY CHANGE A TIRE

• Visually inspect the tire and check the tire for grooves on the side wall.

• If the tire is in good condition, deflate the tire prior to removing it from the vehicle.

• Ensure the tire changer is free of debris and that all guards are in place.

 Check all rings, rim gutters and components for damage, defects, rust and corrosion.

 Inspect the inside of the tires for loose rubber shavings.

• Match tires with rims of the appropriate size.

• Rim parts should never be modified or welded.

• Do not attempt to seat rim parts by hammering on them when the tire is partially or fully inflated.

• Do not stand directly in front of a tire when inflating.

Do not overload tire.

Do not over-inflate a tire.

SIGNS OF A DAMAGED TIRE

- Creases or Wrinkles
- Discoloration
- Bumps
- Broken cords
- Groove in sidewall of tire
- Cuts in liner
- Damage to the rim of the vehicle
- Rubber shavings inside the tire
- Holes or Splits
- Punctures (caused by a sharp object)
- Under-Inflated tire



ALWAYS REMEMBER, SAFETY FIRST